

Wooden

Before the Installation

TOOLS

MATERIALS

1.Do not throw away packing materials until assembly is complete for small parts may come loose inside the carton during shipment. If parts are missing, please contact us.

Sink Drain

- 2. Assemble this item on a soft surface, such as carpet to protect the finish.
- 3. Proper assembly of this item requires 2 people.

Bathroom

- 4. Periodically check to ensure that all connections are tight.
- 5.It is recommended that installation of the product be done by a qualified licensed plumber.

Care and Cleaning

1.To protect the finish, avoid use chemicals and household cleaners.

Vanity Top

- 2.All hot serving dishes should be placed on a pad.
- 3. Any liquid spilled onto the top should be cleaned up immediately with a damp cloth.

Vanity Top (A x 1) Screw decorative cover (C x 2) Expansion bolt (D x 2) Shim (E x 4) Screw (F x 2) Metal gasket (G x 2)

Note: Do not fully tighten all bolts untils all parts are in place. Failure to follow these instructions may cause the bolt to misalign during assembly.



