

Chandelier

Contents

Before Use	
Important Safety Instructions03	3
Warning03	3
Installation Guide	
Assembly Instructions03	3
Parts List04	4
Accessories List05	5
Exploded Views	3
Installation Steps07	7
Operation	
Care and Maintenance1	1
Trouble Shooting11	1

Important Safety Instructions

BEFORE INSTALLING FIXTURE, MAKE SURE THEPOWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKERUTILITY BOX.

- · These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- · We strongly recommend that a professional electrician install all direct wire fixtures.
- The lighting fixture is meant for indoor use. DRY LOCATION ONLY
- · It must be connected only to 3-wire, single-phase electrical supply systems.

(provided with ground wire or equivalent protection system)

For your safety, it is strongly recommended that two people install the lighting fixture.

Warning


To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.

Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.

Keep flammable materials away from lit bulb.


Assembly Instructions

- · Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.
- · When assembling place all parts on a soft, clean, and flatsurface such as a carpet to prevent scratches.



Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

TOOLS YOU MAY NEED



Note: It is required to be sure as follows before installation

- The light bulbs shall be tested lit before bulbs are assembled and lamp shades are installed.
- · The electric wire length needs to be determined in advance.

Parts List


Ax1	Bx62
Cx62	Dx62
Ex1 Pre installed accessories	


Accessories List

Fx2	Gx2
Hx2	lx2
	Pre installed accessories
Jx186	Kx1 ON OFF ON OFF * ON ON ON OFF * ON ON OFF * ON ON OFF * ON ON ON OFF * ON ON ON OFF * ON O

Exploded Views


EXPLODE





Installation Steps

Step 1




Remove the pre-installed nut first

Step 2


F (2)

G x2




Installation Steps

Step 3




Step 4





Installation Steps

Step 5 I x2



Remote Control Manual


Instructions

1.Code matching: the remote control can only be used after it has been matched with the driver.

Here's how:After connecting the driver with the load lighting fixture (light source) and power supply, turn on the

power, and within the instant of power on (see the light/light source turn on), press (ON). You will see the light (light source) "slowly flash three times", indicating that the code matching and grouping have been successfully completed.

2. Code Cleaning: Select the lamp that needs to clear the code, cut off the power supply first, and reconnect the power supply, within 3 seconds after the power is turned on, press the On-Off key five times, that is, the lamp/light source will "flash six times", confirm the success of the code clearing.



Care and Maintenance



WARNING: Before you perform any cleaning or maintenance work, turn off the electricity at the main circuit breaker panel.

- · Wipe the fixture with a damp, soft cloth.
- · Do not use any abrasive cleaners or cleaners that contain alcohol.
- · When replacing bulbs, use 60-watt MAX for E26/27 bulb and E12/14 bulb, 40-watt MAX for G9 bulb, 20-watt MAX for G4 bulb.

Troubleshooting

Problem	Possible Cause	Solution
The light will not turn on.	A bulb is burned out.	Replace the bulb.
	The power is off.	Ensure the power supply is on.
	There is a faulty wire connection.	Check the wiring. Contact a qualified and licensed electrician if you are not capable to solve wiring problems.
	There is a faulty switch.	Test or replace the switch.
The fuse blows or the circuit breaker trips when the light is turned on.	There are crossed wires or the power wire is grounding out.	Discontinue use of the fixture. Check the wire connections or contact a qualified electrician.
Strobe	Drive Failure	Contact our after-sales service, may need to replace the driver.
	Wiring Error	Rewire according to the manual.
	Light Source Failure	Replace the light source, if the problem can not be ruled out, please contact customer service.
Abnormal noise	Drive Failure	Contact our after-sales service, may need to replace the driver.