Freestanding Bathtub

Contents

Before Use

Installation Guide

Operation

GENERAL GUIDELINES

1.This products must be installed by a fully insured and licensed plumber only. Installation of any our product by anyone other than fully insured and licensed plumber shall void limited warranty. We recommend that such licensed plumber have experience in the installation of products.

2.Please check the product for completeness and possible damage immediately after receiving the goods, and inform your dealer immediately if any damage occurs, we are not responsible for any damages incurred during or after installation.

3.Special precautions:

When cleaning the tiles, please ensure that no ammonia or similar aggressive cleaning agents come into contact with the installed parts

Artificial stone bathtub in use, need to consider the relative temperature difference between water temperature and ambient temperature, can not be in the very cold areas suddenly add high temperature water (preferably less than 50 C), otherwise easy to cause damage to the product due to thermal stress.

Installation Guide

TOOLS REQUIRED FOR INSTALLATION (NOT INCLUDED)

|				
Soft Clothor Blanket	Silicone	Tape Measure	Pencil / Marker	Hammer
Safety Glass	Knife	Level	Caulk Gun	Adjustable Wrench	Channel Lock Pliers

Carefully, remove the tub from it's crate/box.

Important Note: Bathtub must be carried by a minimum of 2 adult people in upside down position only. Do not carry the bathtub by its panel.

To avoid scratches or damages to the bathtub be sure to set it on cardboard with soft blanket on top of it.

Installation Steps

Step 1

Determine the installation position of the bathtub

EXT Ground Drain Pipe:
Diameter 50mm(PVC)

75/80/85cm

35cm

Step 2

Put the side of the bathtub on the soft blanket (as shown in the picture) and connect the drain pipe.

Rotate 90°

soft blanket

Bathtub drain

Gasket(silicon gasket is recommended
and glued to the drain valve)

Seal

Connect to main drain

Step 3

Leakage test

Set your bathtub on two 4x4 pieces of lumber so you can have access from the bottom of the bathtub. Put a tray beneath the bathtub.

Very important! Before proceeding with installation, please check that push pop-up, drain, and integrated overflow are properly sealed and tightened.

Push the pop-up into a close position and fill the bathtub with cold water above the overflow level to test for overflow leakage and drain leakage.

Check for any leaks around the drain and pipe.(NOTE: Due to surface tension, it is normal for a small amount of water to pool around the drain)

If a leakage occurs you may change the rubber ring or tube. You can also contact us for solution.

Once the leakage test was performed you may proceed to the installation.

Step 4

Fix the base to the floor with silicone until the tub is level as a whole.Let it cure for 24 hours before proceeding with other construction.

Step 5

After the installation, please clean the floor, and finally clean the bathtub with a rag dipped in the neutral detergent.

Cleaning&Care

1. Solid surface products have excellent physical properties, food, dust, and bacteria will not invade its surface. Daily maintenance only needs to use sponge, soap or window cleaner, paper towel to remove dust and dirt. To disinfect, you can use diluted bleach and water or other disinfectant to wipe the surface. Do not place colored items in the tank for a long time to prevent seepage.

If the water stays on the surface for a long time (because the water contains a lot of bleach and scale) to form stubborn dirt and affect the appearance, or because of other stubborn stains such as hair dye, food coloring, etc, dip a non-abrasive cloth with a scouring pad The cleaner rubs in a circular motion and enhances the surface with a non-abrasive polish.

2. Do not directly scratch the surface of the bathtub with blades and other hard objects, do not let heavy or sharp objects hit the surface directly, and do not scald with boiling water immediately after rinsing with cold water, so as not to leave marks. If there are scratches on the surface, use 600-1200 mesh water abrasive paper to wipe it, and spray brightener after drying. If there are small white marks, use cooking oil and a dry cloth to wipe the surface lightly