# Wall Mounted Basin Faucet Installation

INSTALLATION MANUAL Tools You will need

Adjustable Wrench	Allen key	Philips Screwdriver	Teflon Tape

**Before the Installation**
1.Check the package and confirm all parts are included. If any part is missing or damaged, please contact us.
2.Do not disassemble the main body,as it has been installed & commissioned correctly & precisely before leaving the factory.
3.Shut off the main water supply prior to beginning installation.
4.Do flush the water supply lines to remove any dirt and debris before installation **(IMPORTANT) .**
5.Make sure to connect the hot/cold inlet pipe correctly.If standing in front,connect hot water pipe to the left and cold water pipe to the right.
6.After the installation,check for leaks and make sure every joint is safely sealed.

Cleaning and Maintenance
1.Rinse with clean water and dry with a soft cloth.
2.Do not use any detergent,acid,polisher,abrasives,or harsh cleaners.
3.Do not use cloth with a coarse surface.

1.Holes size for the built in control valve:70*60*(40-45), the depth between the bottom of the control valve to the tile surface is 40-50mm.

2.Use the tape on pipe threads, connected to the main body (A) cold and hot as required inlet pipe and outlet pipe, checking the leakage before fixing the main body in the embedded hole (keep the horizontal and vertical). And assembling the protection plastic cover (B).

3. Remove the prastic cover (D) and then put the base through the cartridge cover(C), use Alleny key(E) and the hexagon socket screw to assemble the handle(F) to the body, and then put on the decorative button(G).

4.Fix the positioning block (H) with the screw in the position of the wall, and then tighten the thread pipe(I) to the water pipe.

5. Fix the spout (J) to the position block and the thread pipe, and then use the Allen key(E) to tight the spout with the thread pipe.

6.Finished.