

# **Bathroom Mirror with Side Cabinet**

# **Contents**

Before Use	
Important Safety Instructions	03
Warning(	03
Installation Guide	
Assembly Instructions	04
Parts List	05
Accessories List	06
Installation Steps	<b>)7</b>
Operation	
Use and Maintenance	12
Trouble Shooting	12

### **Important Safety Instructions**

DANGER – To reduce the risk of electric shock:

Switch off the electrical supply at the main circuit board BEFORE installation and maintenance .

Always unplug this furnishing from the electrical outlet before cleaning or servicing.

Connect this furnishing to a properly grounded outlet only.

- 1. Suitable for indoor use only. This furnishing should be positioned well away from curtains and fabrics. Never cover the mirror.
- 2. We strongly recommend that a professional electrician install all direct wire fixtures.
- 3.Regularly check the cord, the transformer and all other parts for damage, if any part is damaged the product should not be used.


### Warning

To reduce the risk of burns, fire, electric shock, or injury to persons: 1. Unplug from outlet before putting on or taking off parts.

- 1.Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.
- 2.Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer. 4. Never operate this furnishing if it has a damaged cord or plug,
- 3.If it has been dropped or damaged, or dropped into water. Return the furnishing to a service center for examination and repair.
- 4. Keep the cord away from heated surfaces.
- 5. To disconnect, turn all controls to the off position, then remove plug from outlet.
- 6. Do not disassemble the product, as the light diodes can cause damage to the eyes.

### **Assembly Instructions**

1.Please carefully read these instructions before installation and retain for your future reference









TIME

2 People


**DIFFICULTY** 

- 3. This product contains glass parts. Care must be taken when fitting or handling these parts to prevent personal injury or damage to the products.
- 4. When assembling place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.
- 5. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

### **Tools You May Need**



# Parts List




### **Accessories List**

Cx4	Dx4
Ex1	

You may need to purchase extra specific mounting set if the installation is for plaster wall.


Using incorrect mounting screws may result in instability and potential damage to your wall and the mounted item.

## Step 1



Step 1: Select the location of the wall space to be installed. Measure the distance of the product hook with a ruler, measure the same distance on the wall (if the product has only one hanging hole, you can skip this step), and mark the hole position on the wall with a pen.

# Step 2





Step 2: Punch holes at the marked positions with an electric drill, the depth of which is the length of the expanded rubber cap.

# Step 3 C Step 3: Plug the expansion rubber cap into the hole.

# Step 4


D x4







# Option 1 Both gives out lights


# Step 6



Option 2 Only the mirror gives out lights







### **Use and Maintenance**

- 1.Clean the mirror regularly using a soft, lint-free cloth and a mild, non-abrasive cleaner.
- 2. Avoid using harsh chemicals or abrasive materials.
- 3. Open the doors of the furnishing with appropriate force, and it is strictly forbidden to open and close them violently, which will cause loose connections.
- 4. Screws may become loose during long-term use. If necessary, re-tighten them to ensure stability and security.

### **Trouble Shooting**

Problem	Cause Analysis	Handing Method
LED Lights Not Working	Loose electrical connections	Check the power source and ensure the mirror is properly connected to electricity
	Faulty LED components	Contact the manufacturer for assistance or a possible replacement
	Electrical wiring issues	Check for loose or damaged wiring and reattach or replace as necessary
Uneven or Flickering Light	Loose wiring	Check for loose or damaged wiring and reattach or replace if necessary
	Inconsistent power supply	Ensure a stable power supply; fluctuations can cause flickering
Mirror Not Responding to Touch Controls	Dirt or smudges on the touch- sensitive surface	Clean the touch-sensitive area with a soft, lint-free cloth; Ensure that the touch controls are not obstructed by any objects
Discoloration or Dark Spots on the Mirror	Damage to the reflective coating	Inspect the mirror for any physical damage to the reflective surface and replace if necessary